


## QUICKSTART GUIDE

## XS/XS-R/XS-G

### BATTERY



To change the battery unscrew the head fully and replace the battery, making sure the polarity is correct.

### MODES

Rotate the head ON - OFF - ON within 3 seconds to change mode.

A rapid flash will occur after 3 seconds to indicate the light is set in the correct mode.

If the light is ON for more than 3 seconds and then turned OFF, when it's turned ON the last mode will be active.



MODE	DISPOSABLE BATTERY CR123A	RECHARGEABLE BATTERY RCR123A
	BURN TIME	BURN TIME
HIGH	7hrs	4hrs
LOW	60hrs	40hrs

### ATTENTION

Your EXPOSURE XS can use either disposable or rechargeable batteries. We recommend you use EXPOSURE cells as performance will vary between manufacturers. A rechargeable pack is available and contains 2 rechargeable cells and a charger.


Ask your EXPOSURE dealer for EXPCR123CHARGER.

**IMPORTANT** - Reapply silicone based lubricant if the head becomes tight, ensure the o-ring seal is active and wash with fresh water regularly to prevent corrosion.

## GUIDE DE DÉMARRAGE

## XS/XS-R/XS-G

### PILES



Piles : Pour changer la pile, dévisser la tête et la remplacer en s'assurant que la polarité est correcte.

### MODES

Tourner la tête de la lampe en position ON - OFF puis ON en moins de 3 secondes et vous serez passé d'une forte intensité lumineuse à une intensité basse. Un éclat de lumière aura lieu après 3 autres secondes pour valider la modification de l'intensité de la lumière.

Si la lumière est allumée pendant plus de 3 secondes et qu'elle est mise en mode OFF, lorsqu'elle sera rallumée, elle se remettra dans le mode de fonctionnement qui était en cours avant d'être éteinte.



MODE	PILE CLASSIQUE CR123A	PILE CLASSIQUE RCR123A
	DURÉE	DURÉE
FORTE INTENSITE	7hrs	4hrs
BASSE INTENSITE	60hrs	40hrs

### ATTENTION

Votre EXPOSURE XS peut utiliser des piles soit jetables soit rechargeables. Nous vous recommandons d'utiliser une cellule EXPOSURE car la performance de la pile aura tendance à varier selon le fabricant. Un kit de batterie rechargeable est disponible et contient 2 piles rechargeables ainsi qu'un chargeur. Si ça vous intéresse, il suffit de demander à votre vendeur d'exposition pour le EXPCR123CHARGER.

**IMPORTANT** - Si la tête devient trop serré, renouveler l'application du lubrifiant à base de silicone, vérifier que le joint torique est actif et laver à l'eau fraîche régulièrement afin d'éviter la corrosion.