

QUICKSTART GUIDE

X2 S-LINE

EXPOSURE MARINE X2-SLINE CASE INCLUDES

- Exposure Marine X2 S-LINE
- USB charging lead
- Quickstart Guide

HOW TO OPERATE YOUR LIGHT

To turn on the light

Double click the left button to activate the primary two white LEDs, the light is now operating in the lowest mode. To scroll through the modes press the button once. The mode selected will be indicated for two seconds (see mode indicator). After two seconds the button will indicate the amount of battery in the torch (see battery indicator).

To turn off the white light

Press and hold the left button for two seconds.

Locator buttons

The white and red button will pulsate for 12 hours after operation making the light easier to find in the dark. The white button will pulsate in GREEN and the red button will pulsate in RED.

To activate flashing white light

The WHITE flashing mode can be activated from any of the primary WHITE constant modes. Press and hold the left button for 4 seconds. Release button when flashing starts. To return to the low mode click the left button once.

To activate SOS white light

Press, release, press and hold the left button for 5 seconds until S.O.S is activated. To turn OFF hold down the left button for two seconds until S.O.S stops.

To turn on the red light

Double click the right button to activate the secondary red LED, the light is now operating in the lowest mode. To scroll through the modes press button once. The mode selected will be indicated for two seconds (see mode indicator). After two seconds the button will indicate the amount of battery in the torch (see battery indicator).

To turn off the red light

Press and hold the right button for two seconds to turn off the light.

Momentary switch

Press and hold either button for instant light output. After holding for one minute the light will go out to prevent accidental prolonged activation. The light builds from a low output to maximum output in a stepped change over two seconds, preventing an accidental burst of bright light. This change also gives your eyes a second to become accustomed to the bright light.

Mode Indicator

Red (Low) - Amber (Medium) - Green (High)

Battery Indicator

Green 100% - 50% Amber 50% - 25% Red 25% - 5% Red Flash 5% - 0% - at this point the output will drop to low mode giving approximately one hour of burntime.

ITM

New patented technology combating the loss in efficiency of LEDs at elevated temperatures. ITM fine tunes the current before the LEDs become inefficient. When ITM is activated the buttons will flash RED and GREEN alternately.



CHARGING

It is advised to charge your light every time you have an opportunity to ensure it has maximum power. Once your fuel indicator on the function button is red you have your last 25% of battery. You should aim to charge the battery at this time. The charger head will magnetically attach to the light, locating over the terminals. When charging, the left button will flash red. From empty the light unit will take approx. 4 hours to rapid charge up to 95%. At this point the LED on the charger will go from red to green, and trickle charge to 100%. This could take up to an additional 1hr to reach max charge.

MAINTENANCE

Inspect and test your Exposure Marine light before every outing in the dark. Keep your Exposure Marine light clean, and the lenses free of dirt. The lenses are made of hi-tec plastic but can be scratched. Be careful when cleaning any mud or dirt from the lens. Never use a high pressure spray or hose on your Exposure Marine light. Do not use harsh abrasive or corrosive materials to clean your Exposure Marine light. Follow all charging instructions. If the unit is being stored for long periods, please ensure the battery is periodically charged fully.

It is very important to wash your light with fresh water after using in a salt water environment. Ensure there is no water on charge terminals before charging.

Exposure Marine lights are waterproof, sealed to IPX8 - 5meters, under normal marine conditions associated with marine sport activities.

The marine range are not diving lights. If moisture does appear in the unit do not use it and contact Exposure's service department.

Never attempt to disassemble the light unit. This will invalidate your warranty. Do not attempt to use any other chargers or batteries with the unit this will cause damage and is dangerous.

WARNING !

Exposure Marine lights are a very powerful lighting system. Always use care when operating. Do not look directly into the light. This may cause serious injury. Do not shine directly at others. Exposure Marine/USE Ltd. accepts no liability for any injuries or other damages arising from the use of this product in any circumstances.

MAGNETIC FIELD !

Keep magnets away from electronic devices and objects that could be damaged by strong magnetic fields.

For more information please visit exposurelights.com

